

Prepare Foundation Wall:



Pour Wall with Openings for KS4 PowerHooks:



Conduit & Chases installed per drawings:



Hook Pans installed in wall openings:



Prepare front wall with lumber form for Floor Pour & Front Angle Iron



Back fill with Gravel prior to Floor Pour:



Poured Continuous Pit Floor:



Poweramp Supplied Rear Embed:

Must be installed square to pit floor & parallel with front wall/curb angle.



Warehouse Finished Floor Pour:



Stanchion Installation, Welded to Embedded "C" Channel:



