
 <small>A Division of Systems, LLC</small>		<h2 style="margin: 0;">Hold-Tite®</h2> <h3 style="margin: 0;">PM Checklist</h3>			
Customer:		Order #:		Date:	
Address:				Equipment Model:	
 WARNING		Always read and understand the Owner's/User's Manual and become thoroughly familiar with the equipment and its controls before installing or operating equipment. Failure to read and understand the owner's/user's manual could result in death, serious injury, damage to equipment or voiding of warranty!			
Maintenance Steps		Dock #	Dock #	Dock #	Dock #
		Serial #	Serial #	Serial #	Serial #
Weekly Maintenance		Completed Steps			
1) Operate the dock leveler and restraint through the complete operating cycle to maintain lubrication.					
2) Verify all inside and outside signal lights operate correctly. Verify audible alarm. (If applicable.)					
3) Inspect warning decals and placards. Replace if damaged or missing.					
4) Inspect the slide block track and push rod areas.					
5) Remove all debris inside base weldment.					
Quarterly Maintenance					
1) Complete weekly maintenance.					
2) Clean and lubricate slide block track and push rod areas.					
3) Inspect and clean proximity switches and wiring.					
4) Inspect all anchors, concrete and curb steel.					
5) Inspect junction box for moisture and verify electrical connections.					
6) Check reservoir fluid level and inspect inline filter.					
Annual Maintenance					
1) Perform quarterly maintenance.					
2) Change hydraulic oil (may be required more often depending on environment)					

Dock#	Comment or Description of Repair(s) Needed	Approval	Completed

Notes: (Detail adjustments performed, parts replaced, etc.) _____

By signing below I/we certify that all steps required by Systems, LLC have been completed:

Service Provider Representative (print name & sign):	Date:
Customer/End User Representative (print name & sign):	Date:

Recommended Spare Parts – Hold-Tite® Restraint

Quantity	Part Number	Description
1	0961-0073	Proximity Switch DC,18mm
1	8581-0004	Delta Coil,115VAC,DHC-11
1	8581-0011	Solenoid Valve, 4-way, 2-position (High amp Draw)
1	8581-0149	Solenoid Valve, 4-way, 2-position (Low amp Draw)
1	4305-0319	Cable Assembly, 22"Oal, 1 Coil
1	0961-0563	Stored Proximity Switch